

Wireless Status Display with push-button for 55 mm frames

Product ref.: 142408A0
PRODUCT FEATURES



- Wireless status display with energy-saving ePaper works as status display and push-button for comfortable control of connected Homematic devices
- Multiple actions can be performed simultaneously at just one touch of a single button
- No restrictions regarding names you can enter for devices and rooms
- Can be mounted with the attachment frame provided or integrated into an existing multi-gang frame
- Easy to integrate into existing switches from the following manufacturers: Berker (S.1, B.1, B.3, B.7 Glas), Busch-Jaeger (balance SI), GIRA (System 55, Standard 55, E2, E22, Event, Esprit), Merten (1-M, Atelier-M, M-Smart, M-Arc, M-Star, M-Plan) JUNG (A 500, AS 500, A plus, A creation) and ELSO (Joy)
- Can be positioned anywhere in the room thanks to battery operation
- Direct teach-in, as well as integration and programming via the Homematic Central Control Unit CCU2
- Up to 20 devices (max. 10 per channel) can be connected
- A changed status (e.g. opening of a window) or a changed system state (e.g. present/absent) can be signalled acoustically

TECHNICAL SPECIFICATIONS

Supply voltage:	2x 1.5 V LR03/micro/AAA
Current consumption:	50 mA max.
Degree of protection:	IP20
Dimensions (W x H x D):	
without frame	86 x 86 x 19 mm
including frame	55 x 55 x 19 mm
Radio frequency:	868.3 MHz
Ambient temperature:	5 to 35 °C

LOGISTIC DATA

Product reference:	142408A0
EAN code:	4047976424085
Short description:	HM-Dis-EP-WM55
Packing unit:	90
Packaging dimensions:	122 x 112 x 48 mm
Total weight:	178.3 g

PACKAGE CONTENTS

Wireless Status Display with push-button for 55 mm frames
 2 x 1.5 V LR03/micro/AAA batteries
 1 x Clip-on frame
 1 x Mounting frame
 2 x Double-sided adhesive stripes
 2 x Screws 3.0 x 30 mm + plugs
 Operating manual in DE and EN